

Sterilization Procedure for Cannulas and Handles

Cannulas and Handles must be sterilized before each use.

Each Cannula and/or Handle must be:

- Immersed in hot, soapy water
- Carefully scrubbed internally with a Cannula Brush
- Dried
- Packaged
- Autoclaved at 265 – 270 degrees with 25 psi for at least 15 minutes.